

# PICO FIRMWARE UPGRADE INSTRUCTIONS

Download and Install the latest SIMARINE application.

iPhone



<https://apps.apple.com/us/app/simarineapp/id1587666762>


Android phones




<https://play.google.com/store/apps/details?id=com.net.simarine.simarineapp>

## Instructions – Firmware upgrade


1. Power ON your PICO
2. Connect your Android device to the Pico's WiFi.
  - SSID: "Pico" + last 4 numbers of the product number
  - PASSOWRD: "pico" + first 4 numbers of the product number
3. Start the installed application.
4. On the Live view screen press the settings button (green arrow).



5. Select "Device Settings"




6. In the list of settings select the "FIRMWARE Upgrade" button.
7. Confirm the update on your PICO Monitor.



## Instructions – EMERGENCY Firmware upgrade

1. Power ON your PICO. As soon as the SIMARINE logo appears, press and hold the left arrow button. *Warning: You must be quick as the logo disappears quickly.*

Under the SIMARINE LOGO on the display a series of dots will appear (image on the left side) and afterwards PICO will enter in the Emergency Firmware Upgrade mode (image on the right side). You can now release the left arrow button.



2. Connect your Android device to the Pico's WiFi.
  - SSID: "Pico" + last 4 numbers of the product number.
  - PASSOWRD: "pico" + first 4 numbers of the product number.
3. Start the installed application.
4. Click the "FIRMWARE UPGRADE" button.

